

Hound Heater Installation Instructions

Tools Required:

You will need a measuring device, drill, 1 1/8" wood bit, screw driver and five wood screws (not included).



- Step 1.... Place template corner in upper corner of your dog house so the cord hole to be drilled is approximately 11" down and 7" over from the upper corner of the house. This will maintain a minimum clearance of 4" from the ceiling of the dog house. Tape down template Fig. #1
- Step 2.... Place the bit in the center of the template's black circle. Fig. #1
- Step 3.... Drill a hole all the way through the wall. Fig. #3
- Step 4.... Carefully feed the cord all the way through the previously drilled hole making sure the cord is not kinked. Fig. #4
- Step 5.... Mount the heater with the flat side up (top of heater) and the slant (bottom of heater) towards the floor. Using three wood screws. Fig. #5
- Step 6 ... Mount the heat shield approximately 1/2"-1" directly above the heater. The purpose of the shield is to deflect the rising heat and disperse it more efficiently in your pet's house. Fig. #6
- Step 7 ... Set the thermostat to the desired temperature for your pet (medium is most common). Fig. #7
- Step 8 ... Plug the unit into a **GFI outlet** and you are done. If you are using an extension cord, it must be a 3 wire, 18 gauge grounded plug cord. Be sure the connection is elevated off any surface and not near water.

The Hound Heater Dog House furnace is powered by a long lasting 150 watt heating element.

When you turn the thermostat clockwise you will hear a faint click. The unit will turn on and run at maximum power until that chosen temperature is reached.

Because all dog houses are different sizes, shapes, insulation values, etc., reaching the desired temperature will vary greatly. It is **EXTREMELY** important that your house be insulated and preferably have a door/flap.

WARRANTY

If you should experience ANY PROBLEMS with your Hound Heater, please contact the Hound Heater Company directly. DO NOT contact your place of purchase. Contacting Hound Heater will greatly speed up your service. Please go to: www.houndheater.com and use the email contact on the site or simply use: Houndheater@gmail.com